

**“U”
Shower Rod**

Cat. No.
4140



INSTALLATION INSTRUCTIONS

Parts Included

- 2 Corner Pieces • 1 Front Bar with Grey Inserts •
- 2 #300 Flanges • 8 Wall Screws • 2 Set Screws •

Tools Needed

- Pencil • Drill • Measuring Tape • Hacksaw (Optional) •



1. The bent corner rods and small straight rods attach together with the grey inserts as shown.
2. The flanges attach to the wall (measure for proper distance).
3. The U-Rod assembly fits into the flanges and is secured with set screws.
4. Rods can be adjusted to fit by cutting them with a hacksaw.