
INSTALLATION INSTRUCTIONS

Parts Included

- 1 Valve Body • 1 Gooseneck Spout • 2 Large Locknuts • 2 Connecting Nuts • 62" Riser • 3 Porcelain Levers •

Tools Needed

- Adjustable Wrench • Slip Joint Pliers • Pipe Putty or Teflon Pipe Tape •

**NOTE: Handles are identified HOT and COLD.
The hot handle must be to the left and cold to the right.**



1. Align the valve assembly with the holes in the tub and secure with the nuts. Tighten with a wrench or pliers.
2. Apply teflon tape to both ends of the hot and cold supply nipples. Thread the tapered ends (Blue Ends) of the nipples into the mounting flanges. On the outside of the tub, thread the large locknuts onto the other ends of the nipples and secure the shower set to the tub.
3. Connect the water supply nipples to the water supply tubes. For wall mounting of the diverter to a house water supply line, see your local plumber.

NOTE: Please seek professional help if you have copper plumbing in your home.

Cleaning Instructions

Wipe this whole set off with warm water and a soft cloth. DO NOT use soaps, cleansers, or brass cleaners as they will disintegrate the protective lacquer coating and leave the brass exposed causing it to tarnish.