

Installation Instructions for Cast Iron Side Mount Window Stop #204894

The window stop is designed to hold open windows that will no longer remain up by themselves. Old windows with a broken spring or counter-weight string can now be held open without using sticks or wood blocks.

- 1) Position and secure the lower sash in the desired open position.
- 2) Position the stop on the side jam so that the hook portion is securely under the bottom of the lower sash. Mark the location of the screw hole and drill a 3/32" diameter pilot hole.
- 3) Screw the stop to the side jam. Carefully make sure the stop will hold the window in the open position and not slip out.
- 4) If trim or the window track does not allow the stop to be mounted flush with the side jam, a wood shim or spacer is required. Such a spacer is firmly attached to the side jam and then the stop is screwed into the spacer. See the drawing below.

