

installation instructions:

CROSSHEAD/PEDIMENT

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

Medallions are not load bearing. Do not use them to support electrical fixtures or ceiling fans.

TOOL & MATERIAL CHECKLIST

- construction adhesive
- elastomeric adhesive caulk
- caulking gun
- finishing nails
- hammer
- putty knife
- extra fine sandpaper
- tape measure
- jigsaw or keyhole saw

IMPORTANT INFO

- It is highly recommended that you paint/finish our crossheads before you install them. Once installed, you can apply any necessary touchup paint/finish.
- Clean installation surface and back of crosshead of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the crosshead are completely dry before attempting installation.

INSTALL INSTRUCTIONS:

1. Lay the crosshead face down on a soft surface that will not scratch/dent the medallion detail.
2. Apply a continuous 1/2" bead of adhesive caulk along the back of the crosshead.
3. Place the crosshead on top of the entrance opening.
4. Align crosshead with the outer edges of the opening or pilasters. (Note: The crosshead can be slightly larger than the opening as long as the overhang is equal on both sides.)
5. Fasten the crosshead using PL Premium Construction Adhesive and any necessary fasteners.
6. Use a finger or putty knife to smooth any excess adhesive around the crosshead.
7. Use latex caulk to seal edges around crosshead. Use a finger or putty knife to smooth caulk.
8. Touch up crosshead using a high quality latex paint.

EXAMPLE DIAGRAM:

