

2. FLIP THE CATCH PLATE OVER.



1. OPEN THE SCREW ON THE BODY

