

VAN DYKE'S RESTORERS

Sliding Door Hardware Installation Guide

PREPARATION:

- The finished door should be approximately 2" taller and 3" wider than the finished opening.
- The finished opening should not have trim applied to the side the door will be mounted on.

INSTALLATION:

- 1) Install the roller straps on the top edge of the door. The locating pin on the back of the strap should rest directly on the top of the door.
- 2) Locate and mount rod and wall mount brackets so the door will be approximately 5/8" – 7/8" above floor covering. **NOTE: Wall mount bracket screws must be mounted into studs behind sheetrock or plaster.**
- 3) Install door with roller straps onto rod. Position center guide so door will hang parallel to the wall and centers over the opening. Position and mount right and left stops on either end of open and closed door.
- 4) Install end stops on rod.



Complete Installed Door



Wall Mount Bracket



Rod End Stop



Center Guide



Left End Stop



Right End Stop